

## ONBOARD SYSTEMS INTERNATIONAL

**Alert Service Letter** 

Document No. 159-027-00 Rev. 1 Date: September 2, 2009

13915 NW 3<sup>rd</sup> Court Vancouver, WA 98685

USA

Subject:

Importance of ensuring the load beam is closed and locked before installing the mechanical release cable and setting the free play on

TALON<sup>TM</sup> Keeperless style cargo hooks.

Phone: 360-546-3072

Dear Valued Customer:

200-288-00, 200-289-00

200-290-00, 200-291-00

200-329-00, 200-330-00

200-292-01


200-326-00

200-327-00, -01

Fax: 360-546-3073 Toll Free: 800-275-0883

Onboard Systems has received reports from the field about operators rigging the mechanical release cable on the TALON Keeperless style cargo hooks with the load beam in the open position, which could lead to an inadvertent load release. Our records indicate that your company may have purchased equipment that may be affected under one of the following part or kit numbers:

www.OnboardSystems.com



Robinson R44 Cargo Hook Kit

Robinson R44 Cargo Hook Kit

Robinson R44 Cargo Hook Kit

Eurocopter AS355 Swing System

Eurocopter BO105 Replacement Hook Kit

Bell 407 Fixed Beam Suspension System





Flow Monitoring Systems




Customer Directed Development

Please review this information and determine if the equipment is still in your possession. If this equipment is no longer in your possession, please forward this notice to the current owner or your customer, as applicable.

It is critical that the load beam of the Onboard Systems TALON Keeperless style cargo hook is closed and fully locked before installation of the mechanical release cable and setting the cable free play. If the free play is set while the load beam is in the open position, when the load beam is closed it may reduce the amount of free play to an unsafe level that will not allow adequate margin of safety during external load operations. The reduced level of free play on the cable may result in inadvertently activating the release mechanism on the hook during operations, which could cause an inadvertent load release.

The following pictures illustrate the proper and improper load beam positions.




## FIGURE 1

Picture of proper load beam position. The cargo hook load beam is fully closed and locked, ready to set the mechanical cable free play (circled in yellow).

## FIGURE 2

Picture of improper load beam position. The cargo hook load beam is open. If the mechanical cable free play is set now, there may not be enough free play in the cable (circled in yellow) when the hook is closed.



The information contained in this service letter is currently being added to the technical documentation that was originally supplied with the equipment, either in the Owner's Manual, Rotorcraft Flight Manual Supplement or Instructions for Continued Airworthiness, and will be available shortly. Revisions for these manuals will be available for download from our company website at the following link:

http://www.onboardsystems.com/Support/Manuals\_and\_Documents.php

Onboard Systems is dedicated to supporting helicopter external load operators. We welcome any feedback and comments you may have. If you have any questions or require additional information, please feel free to contact us.

Best regards,

Karsten Lemmon

Vice President, Sales and Marketing Phone: 360-546-3072, Ext. 215

E-mail: Karsten@OnboardSystems.com